



Electrical Raceway Planning: Fill to Pull Box

A conduit run is a pull system. Fill, bends, boxes, and conductor heat limits must agree before wire is ordered or pulled.

Conduit that appears large enough can still create a difficult, damaging pull or an undersized box.

Worked example from the live calculator

The live conduit-fill calculator puts three 12 AWG THHN conductors in 1/2 in EMT at 13% fill, within the 40% limit, and recommends that raceway size.

Start with fill and conductor count

Conduit fill establishes a physical limit, while conductor count can trigger ampacity adjustment. Check both whenever the circuit list changes.

Lay out bends as a pulling problem

Offsets and accumulated bends affect pull difficulty. Plan accessible pull points instead of forcing conductors through an optimistic route.

Size the boxes for the conductors that enter them

Pull-box dimensions and box fill are separate checks. A large raceway does not make a small box acceptable.

Key takeaway. A raceway design is complete only when fill, heat, bends, and boxes all pass together.

Assumptions

- Conductor insulation, raceway type, bend count, and local code enforcement affect the final installation.

Sources

- NEC Chapter 9 and Articles 314 and 310, verify adopted edition

Frequently asked questions

Is conduit fill the only rule?

No. Derating, bend limits, and box dimensions also apply.

Can a pull box be any convenient size?

No. Required dimensions depend on raceway layout and conductor size.

Does an offset change conductor length?

Yes. Account for the actual route and pulling geometry.

TradesWorkbench is a set of transparent decision engines for the trades, not a substitute for a licensed professional, a permit, or an inspection. This guide is educational, not a guarantee of any outcome.